Roland

EXPANSION BOARD

Super Sound Set

from SO-PCM1

SR-JV80-07

OWNER'S MANUAL

Copyright © 1995 ROLAND CORPORATION
All rights reserved. No part of this publication may be reproduced in any form without the permission of ROLAND CORPORATION.

本書の一部、もしくは全部を無断で複写・転載することを禁じます。

Thank you for choosing the Roland SR-JV80-07 "**Super Sound Set**" wave expansion board.

Your new expansion board not only gives you all the Waveforms, Patches and Rhythm Sets originally provided on cards 01 through 08 in the SO-PCM1 Series Sound Library (except for 04), but also includes completely new Patches created by combining the use of multiple SO-PCM1 Series cards.

In addition to the pianos, guitars, brasses, and drum sections that are essential for the Pop scene, there are also numerous other Waveforms offering traditional favorites such as banjos, mandolins, steel guitars and accordions. Moreover, a good collection of organs, harpsichords, orchestra hits, and harps (with typical performance techniques represented) allows you to readily cover classical music as well.

● **Waveforms: 255 Kinds**
Most of the Waveforms that made the SO-PCM1 series as popular as it was, such as piano, guitar, brass, drum section, organ, harpsichord, orchestra hit, harp, banjo, steel guitar and accordion are included.

The board provides almost all the Waveforms that were in the SO-PCM1 Series Sound Library (except for 04). Some of them may sound slightly differently than the SO-PCM1 Series cards did, however. (The Waveforms of the SO-PCM1-04 "Grand Piano 1" are in the JV-90/1000 /1080 and XP-50's internal memory.)

● **Patches**
255 kinds designed for the JV-1010/1080/2080 & XP series; another 220 for the JV-80/880/90/1000.

● **Rhythm Sets**
Eight kinds designed for the JV-1010/1080/2080 & XP series; another two for the JV-90/1000.

The Rhythm Sets in this expansion board cannot be used with the JV-80/880 or JD-990.

■INSTALLING THE EXPANSION BOARD

*** Turn off your instrument.**

1. Remove the cover located on the bottom (or top) of your instrument.
2. Check that the plastic board holders are positioned as shown. Rotate them if necessary.
3. While positioning the holes on the board over the board holders, carefully insert the connector on the board into the socket on the instrument. Make sure the connector is securely connected, and that all three board holders project through the holes.
4. Use the supplied Installation Tool to turn the holders in the LOCK direction, so the board will be fastened in place.

   (To remove the Expansion Board, turn the board holders in the UNLOCK direction, and lift up the board using the provided tool. Remove the board and secure the cover plate.)
5. Check if the Expansion Board is correctly installed.

   If the "EXP" display cannot be selected (doesn't appear) in the Waveform Selection Screen (refer to the owner's manual of the instrument you use), remove the Expansion Board and install it properly.

このたびは、ウェーブ・エクスパンション・ボードSR-JV80-07「スーパー・サウンド・セット」をお買い上げいただきまして、まことにありがとうございます。

このエクスパンション・ボードは、サウンド・ライブラリーSO-PCM1シリーズの01から08(04を除く)に含まれていたウェーブフォーム、パッチ、リズム・セットを網羅し、さらにSO-PCM1シリーズを複数組み合わせて作成した新作パッチも追加したエクスパンション・ボードです。

ポップ・シーンには欠かせないピアノ、ギター、ブラス、ドラム・セクションはもちろんのこと、オルガン、ハープシコード、オーケストラ・ヒット、ハープなどのクラシック音楽ならではの特徴のある楽器や奏法を集め、またバンジョーやマンドリン、スチール・ギターやアコーディオンなどの郷愁あふれるウェーブフォームも数多く内蔵されています。

●ウェーブフォーム：255種類
ピアノ、ギター、ブラス、ドラム・セクション、オルガン、ハープシコード、オーケストラ・ヒット、ハープ、バンジョーやマンドリン、スチール・ギター、アコーディオンなどのSO-PCM1シリーズで定評のあるウェーブフォームがそろっています。

本エクスパンション・ボードのウェーブフォームは、サウンド・ライブラリーSO-PCM1シリーズ(04を除く)のほとんどを内蔵していますが、SO-PCM1シリーズとは多少音色の異なるものもあります。(SO-PCM1-04「Grand Piano 1」のウェーブフォームはJV-90/1000/1080, XP-50の本体に内蔵されています。)

●パッチ
JV-1010/1080/2080, XPシリーズ専用：255種類　JV-80/880/90/1000専用：220種類

●リズム・セット
JV-1010/1080/2080, XPシリーズ専用：8種類　JV-90/1000専用：2種類

JV-80/880, JD-990では、エクスパンション・ボードのリズム・セットを使用することはできません。

■エクスパンション・ボードの取り付けかた

＊使用機器の電源スイッチをオフにしてください。

1. **使用機器の底部、または上部にあるカバーをはずします。**
2. **基板ホルダーを、図2のような向きに合わせます。**
3. **エクスパンション・ボードのコネクターを、本体のコネクターに完全に差し込みます。このとき3つの基板ホルダーの頭が、エクスパンション・ボードから出るようにします。**
4. **付属の固定用具で基板ホルダーをLOCK方向に回し、エクスパンション・ボードを固定します。**

   エクスパンション・ボードの取りはずしは、基板ホルダーをUNLOCK方向に回し、固定用具を引っかけて取りはずします。

   最後にカバーを取り付けます。
5. **エクスパンション・ボードの取り付けが正しく行われたかを確認します。**

   ウェーブフォームの選択画面（使用機器の取扱説明書参照）で"EXP"が選べない（表示されない）ときは、もう一度エクスパンション・ボードをつけ直してください。



WAVEFORM LIST

No.	Name
1	U Ac.Piano p
2	U Ac.Piano f
3	U E.Grand p
4	U E.Grand f
5	Rhodes A
6	Rhodes B
7	Rhodes C
8	Bright EP A
9	Bright EP B
10	Bright EP C
11	HPS_Front A
12	HPS_Front B
13	HPS_Front C
14	HPS_Back A
15	HPS_Back B
16	HPS_Back C
17	HPS_Lute A
18	HPS_Lute B
19	HPS_Lute C
20	HPS_Click
21	Ac.Guitar A
22	Ac.Guitar B
23	Ac.Guitar C
24	Reso.GTR p A
25	Reso.GTR p B
26	Reso.GTR p C
27	Reso.GTR f A
28	Reso.GTR f B
29	Reso.GTR f C
30	F.Mandolin A
31	F.Mandolin B
32	F.Mandolin C
33	Dulcimer A
34	Dulcimer B
35	Dulcimer C
36	FretNoise
37	Jazz Gt p A
38	Jazz Gt p B
39	Jazz Gt p C
40	Jazz Gt f A
41	Jazz Gt f B
42	Jazz Gt f C
43	Pd.Steel 1 A
44	Pd.Steel 1 B
45	Pd.Steel 1 C
46	Pd.Steel 2 A
47	Pd.Steel 2 B
48	Pd.Steel 2 C
49	335Pick A
50	335Pick B
51	335Pick C
52	335Mute A
53	335Mute B
54	335Mute C
55	Funk Gt Mute
56	Funk Gt
57	CleanEG A
58	CleanEG B
59	CleanEG C
60	Dist Gt p A

No.	Name
61	Dist Gt p B
62	Dist Gt p C
63	Dist Gt f A
64	Dist Gt f B
65	Dist Gt f C
66	Sax p A
67	Sax p B
68	Sax p C
69	Sax mf A
70	Sax mf B
71	Sax mf C
72	Trombopet A
73	Trombopet B
74	Trombopet C
75	Trombone p A
76	Trombone p B
77	Trombone p C
78	Trombone mf A
79	Trombone mf B
80	Trombone mf C
81	Trombone f A
82	Trombone f B
83	Trombone f C
84	ORG_Flute A
85	ORG_Flute B
86	ORG_Flute C
87	S_Recorder A
88	S_Recorder B
89	S_Recorder C
90	T_Recorder A
91	T_Recorder B
92	T_Recorder C
93	Musette 1 A
94	Musette 1 B
95	Musette 1 C
96	Musette 2 A
97	Musette 2 B
98	Musette 2 C
99	Musette 3 A
100	Musette 3 B
101	Musette 3 C
102	Master A
103	Master B
104	Master C
105	Single A
106	Single B
107	Single C
108	Bandoneon 1A
109	Bandoneon 1B
110	Bandoneon 1C
111	Bandoneon 2A
112	Bandoneon 2B
113	Bandoneon 2C
114	MasterBs A
115	MasterBs B
116	MasterBs C
117	Bs/Musette 1
118	Bs/Musette 2
119	Bs/Musette 3
120	Bs/Master

No.	Name
121	Bs/Single
122	Bs/Bandneon1
123	Bs/Bandneon2
124	Fiddle A
125	Fiddle B
126	Fiddle C
127	Gliss Maj
128	Gliss Min
129	Tremolo p
130	Tremolo sfz
131	Tremolo f
132	Cluster
133	Pentatonic
134	Gliss Maj Lp
135	Gliss Min Lp
136	Tremolo p Lp
137	Tremolo sfLp
138	Tremolo f Lp
139	Cluster Lp
140	PentatonicLp
141	Orch Hit Maj
142	Orch Hit Min
143	Orch hit Dim
144	Orch Hit f
145	Staccato p
146	Staccato f
147	F.Horn Rip
148	Brass Fall
149	Tps Fall
150	Brass Stacc
151	Harp m7 Up
152	Harp m7 Dwn
153	Harp 9th Up
154	Harp 9th Dwn
155	Harp +7 Up
156	Harp +7 Dwn
157	Harp b9 Up
158	Harp b9 Dwn
159	Harp m7 UpLp
160	Harp m7 DnLp
161	Harp 9thUpLp
162	Harp 9thDnLp
163	Harp +7 UpLp
164	Harp +7 DnLp
165	Harp b9 UpLp
166	Harp b9 DnLp
167	Fat BD
168	Pillow BD
169	Mondo Kick
170	Deep Kick 1
171	Solid Kick
172	Ambo Kick
173	Reverb Kick1
174	Deep Kick 2
175	Reverb Kick2
176	Room Stick
177	Snappy SN
178	Cross SN
179	Crisp SN
180	Brash SN

No.	Name
181	Bigshot SN
182	Crack Snare
183	Atomic Snare
184	Power Snare
185	Trash Snare
186	Hard Snare
187	Combo Snare
188	Induced SN
189	Tiny Snare
190	Rock Snare 1
191	Rock Snare 2
192	Reverb Snare
193	SharpTom Lo
194	SharpTom Hi
195	Rock Tom 1
196	Rock Tom 2
197	Rock Tom 3
198	Rock Tom 4
199	Ambo Tom 1
200	Ambo Tom 2
201	Ambo Tom 3
202	Ambo Tom 4
203	Closed Hat 1
204	Closed Hat 2
205	Room Hat 1
206	Room Hat 2
207	Room Hat 3
208	Room Hat 4
209	Open HH
210	Open HiHat
211	Pedal HiHat
212	Claps Real
213	Crash Cym
214	Ride Cym
215	Ride Cymbal
216	Ride Bell
217	China Cym
218	Cowbell 2
219	Tambourine
220	Gong
221	Hat & Tom 1
222	Hat & Tom 2
223	Cymbal
224	Kick & SN 1
225	Kick & SN 2
226	Kick & SN 3
227	Kick & SN 4
228	Kick & SN 5
229	Kick & SN 6
230	Kick & SN 7
231	Kick & Snare
232	Tom Set
233	HiHat Set
234	Ride & Clap
235	REV Hit Maj
236	REV Hit Min
237	REV Hit Dim
238	REV Hit f
239	REV Stacc p
240	REV Stacc f

No.	Name
241	REV Hrp m7Up
242	REV Hrp m7Dn
243	REV Hrp9thUp
244	REV Hrp9thDn
245	REV Hrp +7Up
246	REV Hrp +7Dn
247	REV Hrp b9Up
248	REV Hrp b9Dn
249	REV PillowBD
250	REV SnappySN
251	REV Cross SN
252	REV Brash SN
253	REV Crisp SN
254	REV Tom Hi
255	REV Gong

Waveforms in the list which have "REV" as part of their name are designed to play in reverse when sounding. However, on the JD-990, they will instead be sounded in the forward direction, since the instrument does not support reverse playback.

リストの中で、名前に"REV"が付いているウェーブフォームはリバース（逆方向）再生で発音するようになっていますが、JD-990ではリバース再生ができないため、正方向再生で代用して発音します。

MENU WAVEFORM

Menu Waveforms provide multiple Waveforms, with each one assigned to a different key.

メニュー・ウェーブフォームは、キーごとに異なるウェーブフォームが割り当てられています。

Key	Wave#	Wave Name
221	**Hat & Tom 1**	
F 2	198	Rock Tom 4
F #2	206	Room Hat 2
G 2	197	Rock Tom 3
G#2	207	Room Hat 3
A 2	197	Rock Tom 3
B 2	196	Rock Tom 2
C 3	196	Rock Tom 2
D 3	195	Rock Tom 1
G#3	218	Cowbell 2
A #3	208	Room Hat 4
222	**Hat & Tom 2**	
F 2	202	Ambo Tom 4
F #2	205	Room Hat 1
G 2	201	Ambo Tom 3
G#2	207	Room Hat 3
A 2	201	Ambo Tom 3
B 2	200	Ambo Tom 2
C 3	200	Ambo Tom 2
D 3	199	Ambo Tom 1
G#3	218	Cowbell 2
A #3	208	Room Hat 4
223	**Cymbal**	
A #2	209	Open HH
C #3	213	Crash Cym
D#3	214	Ride Cym
E 3	217	China Cym
F 3	214	Ride Cym
F #3	219	Tambourine
G 3	213	Crash Cym
A 3	220	Gong
224	**Kick & SN 1**	
C 2	173	Reverb Kick1
C #2	176	Room Stick
D 2	186	Hard Snare
D#2	182	Crack Snare
E 2	188	Induced SN
C 6	172	Ambo Kick
C #6	170	Deep Kick 1
D 6	189	Tiny Snare
D#6	176	Room Stick
E 6	182	Crack Snare
F 6	199	Ambo Tom 1
F #6	213	Crash Cym
G 6	195	Rock Tom 1

Key	Wave#	Wave Name
225	**Kick & SN 2**	
C 2	172	Ambo Kick
C #2	176	Room Stick
D 2	184	Power Snare
D#2	183	Atomic Snare
E 2	184	Power Snare
C 6	173	Reverb Kick1
C #6	183	Atomic Snare
D 6	181	Bigshot SN
D#6	191	Rock Snare 2
E 6	187	Combo Snare
F 6	202	Ambo Tom 4
F #6	217	China Cym
G 6	196	Rock Tom 2
226	**Kick & SN 3**	
C 2	170	Deep Kick 1
C #2	176	Room Stick
D 2	181	Bigshot SN
D#2	185	Trash Snare
E 2	187	Combo Snare
C 6	174	Deep Kick 2
C #6	175	Reverb Kick2
D 6	186	Hard Snare
D#6	188	Induced SN
E 6	184	Power Snare
F 6	200	Ambo Tom 2
F #6	205	Room Hat 1
G 6	219	Tambourine
227	**Kick & SN 4**	
C 2	171	Solid Kick
C #2	176	Room Stick
D 2	188	Induced SN
D#2	181	Bigshot SN
E 2	185	Trash Snare
C 6	174	Deep Kick 2
C #6	175	Reverb Kick2
D 6	185	Trash Snare
D#6	182	Crack Snare
E 6	192	Reverb Snare
F 6	201	Ambo Tom 3
F #6	206	Room Hat 2
G 6	197	Rock Tom 3

Key	Wave#	Wave Name
228	**Kick & SN 5**	
C 2	169	Mondo Kick
C #2	176	Room Stick
D 2	184	Power Snare
D#2	182	Crack Snare
E 2	183	Atomic Snare
C 6	174	Deep Kick 2
C #6	170	Deep Kick 1
D 6	185	Trash Snare
D#6	184	Power Snare
E 6	182	Crack Snare
F 6	198	Rock Tom 4
F #6	207	Room Hat 3
G 6	214	Ride Cym
229	**Kick & SN 6**	
C 2	175	Reverb Kick2
C #2	176	Room Stick
D 2	192	Reverb Snare
D#2	191	Rock Snare 2
E 2	190	Rock Snare 1
C 6	174	Deep Kick 2
C #6	187	Combo Snare
D 6	185	Trash Snare
D#6	186	Hard Snare
E 6	198	Rock Tom 4
F 6	219	Tambourine
F #6	208	Room Hat 4
G 6	216	Ride Bell
230	**Kick & SN 7**	
C 2	174	Deep Kick 2
C #2	176	Room Stick
D 2	187	Combo Snare
D#2	185	Trash Snare
E 2	181	Bigshot SN
231	**Kick & Snare**	
B 1	168	Pillow BD
C 2	167	Fat BD
D 2	177	Snappy SN
E 2	178	Cross SN
B 5	167	Fat BD
C 6	168	Pillow BD
D 6	179	Crisp SN
E 6	180	Brash SN

Key	Wave#	Wave Name
232	**Tom Set**	
232Tom Set		
F 2	194	SharpTom Hi
G 2	193	SharpTom Lo
A 2	193	SharpTom Lo
B 2	193	SharpTom Lo
C 3	194	SharpTom Hi
D 3	194	SharpTom Hi
233	**HiHat Set**	
F #2	203	Closed Hat 1
G#2	211	Pedal HiHat
A #2	210	Open HiHat
F #6	204	Closed Hat 2
G#6	211	Pedal HiHat
A #6	210	Open HiHat
234	**Ride & Clap**	
D#2	212	Claps Real
D#3	215	Ride Cymbal

RHYTHM SET LIST

For JV-90 / 1000

■ RhythmSet [A]

Note No.	Wave No.	Wave Name
C2 36	E-167	Fat BD
37	E-176	Room Stick
38	E-177	Snappy SN
39	E-212	Claps Real
40	E-178	Cross SN
	E-193	SharpTom Lo
41	E-203	Closed Hat1
42	E-193	SharpTom Lo
43	E-211	Pedal HiHat
44	E-193	SharpTom Lo
45	E-210	Open HiHat
46	E-194	SharpTom Hi
47	E-194	SharpTom Hi
C3 48	E-195	Rock Tom 1
49	E-213	Crash Cym
50	E-195	Rock Tom 1
51	E-214	Ride Cym
52	E-217	China Cym
53	E-216	Ride Bell
54	E-219	Tambourine
55	E-223	Cymbal
56	E-218	Cowbell 2
57	E-223	Cymbal
58	E-218	Cowbell 2
59	E-223	Cymbal
C4 60	E-141	Orch Hit Maj
61	E-145	Staccato p
62	E-142	Orch Hit Min
63	E-146	Staccato f
64	E-143	Orch hit Dim
65	E-144	Orch Hit f
66	E-148	Brass Fall
67	E-130	Tremolo sfz
68	E-149	Tps Fall
69	E-131	Tremolo f
70	E-147	F.Horn Rip
71	E-172	Ambo Kick
C5 72	E-173	Reverb Kick1
73	E-176	Room Stick
74	E-182	Crack Snare
75	E-212	Claps Real
76	E-183	Atomic Snare
77	E-202	Ambo Tom 4
78	E-222	Hat & Tom 2
79	E-201	Ambo Tom 3
80	E-222	Hat & Tom 2
81	E-200	Ambo Tom 2
82	E-209	Open HiHat
83	E-199	Ambo Tom 1
C6 84	E-199	Ambo Tom 1
85	E-213	Crash Cym
86	E-199	Ambo Tom 1
87	E-214	Ride Cym
88	E-220	Gong
89	E-216	Ride Bell
90	E-219	Tambourine
91	E-217	China Cym
92	E-218	Cowbell 2
93	E-213	Crash Cym
94	E-218	Cowbell 2
95	E-144	Orch Hit f
C7 96	E-145	Staccato p

■ RhythmSet [B]

Wave No.	Wave Name
E-224	Kick & SN 1
E-176	Room Stick
E-229	Kick & SN 6
E-212	Claps Real
E-228	Kick & SN 5
E-198	Rock Tom 4
E-206	Room Hat 2
E-198	Rock Tom 4
E-205	Room Hat 1
E-197	Rock Tom 3
E-208	Room Hat 4
E-196	Rock Tom 2
E-195	Rock Tom 1
E-213	Crash Cym
E-195	Rock Tom 1
E-214	Ride Cym
E-217	China Cym
E-216	Ride Bell
E-219	Tambourine
E-213	Crash Cym
E-218	Cowbell 2
E-250	REV SnappySN
E-218	Cowbell 2
E-252	REV Brash SN
E-235	REV Hit Maj
E-151	Harp m7 Up
E-236	REV Hit Min
E-241	REV Hrp m7Up
E-237	REV Hit Dim
E-238	REV Hit f
E-152	Harp m7 Dwn
E-239	REV Stacc p
E-243	REV Hrp9thUp
E-240	REV Stacc f
E-157	Harp b9 Up
E-169	Mondo Kick
E-174	Deep Kick 2
E-143	Orch hit Dim
E-172	Ambo Kick
I- 075	White Noise
E-176	Room Stick
E-193	SharpTom Lo
E-208	Room Hat 4
E-193	SharpTom Lo
E-207	Room Hat 3
E-193	SharpTom Lo
E-210	Open HiHat
E-194	SharpTom Hi
E-194	SharpTom Hi
E-208	Room Hat 4
E-194	SharpTom Hi
E-210	Open HiHat
E-209	Open HH
E-214	Ride Cym
E-217	China Cym
E-208	Room Hat 4
E-132	Cluster
E-199	Ambo Tom 1
I- 079	Anklungs
E-199	Ambo Tom 1
E-183	Atomic Snare

For JV-1010/1080/2080, XP series

Note No.	■ Drum Set 1		■ Drum Set 2		■ Drum Set 3		■ Drum Set 4		■ Drum Set 5		■ Drum Set 6		■ Drum Set 7		■ Drum Set 8	
	Wave No.	Wave Name	Wave No.	Wave Name	Wave No.	Wave Name	Wave No.	Wave Name	Wave No.	Wave Name	Wave No.	Wave Name	Wave No.	Wave Name	Wave No.	Wave Name
35	E--171	Solid Kick	E--172	Ambo Kick	E--169	Mondo Kick	E--167	Fat BD	E--173	Reverb Kick1	E--168	Pillow BD	E--173	Reverb Kick1	IB-084	808 Kick
C2 36	E--170	Deep Kick 1	E--173	Reverb Kick1	E--174	Deep Kick 2	E--171	Solid Kick	E--175	Reverb Kick2	E--167	Fat BD	E--172	Ambo Kick	E--171	Solid Kick
37	IB-077	Side Stick	IB-077	Side Stick	IB-077	Side Stick	E--176	Room Stick	IB-077	Side Stick	E--176	Room Stick	E--176	Room Stick	E--176	Room Stick
38	E--184	Power Snare	E--184	Power Snare	E--187	Combo Snare	E--179	Crisp SN	E--185	Trash Snare	E--177	Snappy SN	E--183	Atomic Snare	IB-072	808 SN
39	E--212	Claps Real	E--212	Claps Real	E--212	Claps Real	E--212	Claps Real	E--212	Claps Real	E--212	Claps Real	E--212	Claps Real	IB-095	808 Claps
40	E--181	Bigshot SN	E--190	Rock Snare 1	E--186	Hard Snare	E--198	Rock Tom 4	E--192	Reverb Snare	E--179	Crisp SN	E--182	Crack Snare	E--182	Crack Snare
41	E--198	Rock Tom 4	E--202	Ambo Tom 4	E--198	Rock Tom 4	E--202	Ambo Tom 4	E--202	Ambo Tom 4	E--193	SharpTom Lo	E--202	Ambo Tom 4	IB-084	808 Kick
42	E--205	Room Hat 1	E--206	Room Hat 2	E--206	Room Hat 2	E--205	Room Hat 1	E--206	Room Hat 2	E--203	Closed Hat1	E--206	Room Hat 2	IB-093	606 HiHat Cl
43	E--198	Rock Tom 4	E--201	Ambo Tom 3	E--198	Rock Tom 4	E--198	Rock Tom 4	E--201	Ambo Tom 3	E--193	SharpTom Lo	E--201	Ambo Tom 3	E--141	Orch Hit Maj
44	E--207	Room Hat 3	E--211	Pedal HiHat	E--211	Pedal HiHat	E--207	Room Hat 3	E--211	Pedal HiHat	E--204	Closed Hat2	E--207	Room Hat 3	IB-093	606 HiHat Cl
45	E--197	Rock Tom 3	E--200	Ambo Tom 2	E--197	Rock Tom 3	E--197	Rock Tom 3	E--200	Ambo Tom 2	E--193	SharpTom Lo	E--201	Ambo Tom 3	IB-084	808 Kick
46	E--209	Open HH	E--209	Open HH	E--209	Open HH	E--209	Open HH	E--209	Open HH	E--210	Open HiHat	E--209	Open HH	IB-094	606 HiHat Op
47	E--197	Rock Tom 3	E--200	Ambo Tom 2	E--197	Rock Tom 3	E--197	Rock Tom 3	E--200	Ambo Tom 2	E--194	SharpTom Hi	E--200	Ambo Tom 2	E--142	Orch Hit Min
C3 48	E--195	Rock Tom 1	E--199	Ambo Tom 1	E--195	Rock Tom 1	E--196	Rock Tom 2	E--199	Ambo Tom 1	E--194	SharpTom Hi	E--200	Ambo Tom 2	IB-084	808 Kick
49	E--213	Crash Cym	E--213	Crash Cym	E--213	Crash Cym	E--213	Crash Cym	E--213	Crash Cym	E--213	Crash Cym	E--213	Crash Cym	E--213	Crash Cym
50	E--195	Rock Tom 1	E--199	Ambo Tom 1	E--195	Rock Tom 1	E--195	Rock Tom 1	E--199	Ambo Tom 1	E--194	SharpTom Hi	E--199	Ambo Tom 1	E--143	Orch hit Dim
51	E--214	Ride Cym	E--214	Ride Cym	E--214	Ride Cym	E--214	Ride Cym	E--214	Ride Cym	E--214	Ride Cym	E--214	Ride Cym	IA-248	Voice Breath
52	E--217	China Cym	E--217	China Cym	E--217	China Cym	E--217	China Cym	E--217	China Cym	E--217	China Cym	E--217	China Cym	IB-181	MC500 Beep 1
53	E--216	Ride Bell	E--216	Ride Bell	E--216	Ride Bell	E--216	Ride Bell	E--216	Ride Bell	E--216	Ride Bell	E--216	Ride Bell	IB-182	MC500 Beep 2
54	E--219	Tambourine	E--219	Tambourine	E--219	Tambourine	E--219	Tambourine	E--219	Tambourine	E--219	Tambourine	E--219	Tambourine	IB-178	R8 Click
55	IB-101	Crash 1	IB-101	Crash 1	IB-101	Crash 1	IB-101	Crash 1	IB-101	Crash 1	IB-101	Crash 1	IB-101	Crash 1	E--084	ORG_Flute A
56	E--218	Cowbell 2	E--218	Cowbell 2	E--218	Cowbell 2	E--218	Cowbell 2	E--218	Cowbell 2	E--218	Cowbell 2	E--218	Cowbell 2	IB-015	DIGI Bell 1
57	E--220	Gong	E--220	Gong	E--220	Gong	E--220	Gong	E--220	Gong	IB-101	Crash 1	E--220	Gong	IB-055	Rattles
58	E--218	Cowbell 2	E--218	Cowbell 2	E--218	Cowbell 2	E--218	Cowbell 2	E--218	Cowbell 2	E--218	Cowbell 2	E--218	Cowbell 2	IB-100	Ride Bell 1
59	IB-100	Ride Bell 1	IB-100	Ride Bell 1	IB-100	Ride Bell 1	IB-100	Ride Bell 1	IB-100	Ride Bell 1	IB-100	Ride Bell 1	IB-100	Ride Bell 1	E--166	Harp b9 DnLp
C4 60	IB-110	Cga Mute Hi	IB-110	Cga Mute Hi	IB-110	Cga Mute Hi	IB-110	Cga Mute Hi	IB-110	Cga Mute Hi	IB-110	Cga Mute Hi	IB-110	Cga Mute Hi	IB-021	2.2 Vibwave
61	IB-111	Cga Mute Lo	IB-111	Cga Mute Lo	IB-111	Cga Mute Lo	IB-111	Cga Mute Lo	IB-111	Cga Mute Lo	IB-111	Cga Mute Lo	IB-111	Cga Mute Lo	E--139	Cluster Lp
62	IB-112	Cga Slap	IB-112	Cga Slap	IB-112	Cga Slap	IB-112	Cga Slap	IB-112	Cga Slap	IB-112	Cga Slap	IB-112	Cga Slap	IB-001	Kalimba
63	IB-108	Cga Open Hi	IB-108	Cga Open Hi	IB-108	Cga Open Hi	IB-108	Cga Open Hi	IB-108	Cga Open Hi	IB-108	Cga Open Hi	IB-108	Cga Open Hi	IB-050	Metal Wind
64	IB-109	Cga Open Lo	IB-109	Cga Open Lo	IB-109	Cga Open Lo	IB-109	Cga Open Lo	IB-109	Cga Open Lo	IB-109	Cga Open Lo	IB-109	Cga Open Lo	E--019	HPS_Lute C
65	IB-113	Timbale	IB-113	Timbale	IB-113	Timbale	IB-113	Timbale	IB-113	Timbale	IB-113	Timbale	IB-113	Timbale	IB-057	Tin Wave
66	IB-113	Timbale	IB-113	Timbale	IB-113	Timbale	IB-113	Timbale	IB-113	Timbale	IB-113	Timbale	IB-113	Timbale	E--196	Rock Tom 2
67	IB-014	Agogo	IB-014	Agogo	IB-014	Agogo	IB-014	Agogo	IB-014	Agogo	IB-014	Agogo	IB-014	Agogo	E--170	Deep Kick 1
68	IB-014	Agogo	IB-014	Agogo	IB-014	Agogo	IB-014	Agogo	IB-014	Agogo	IB-014	Agogo	IB-014	Agogo	E--195	Rock Tom 1
69	IB-114	Cabasa Up	IB-114	Cabasa Up	IB-114	Cabasa Up	IB-114	Cabasa Up	IB-114	Cabasa Up	IB-114	Cabasa Up	IB-114	Cabasa Up	E--171	Solid Kick
70	IB-117	Maracas	IB-117	Maracas	IB-117	Maracas	IB-117	Maracas	IB-117	Maracas	IB-117	Maracas	IB-117	Maracas	E--199	Ambo Tom 1
71	IA-219	Soft Pad A	IA-219	Soft Pad A	IA-219	Soft Pad A	IA-219	Soft Pad A	IA-219	Soft Pad A	IA-219	Soft Pad A	IA-219	Soft Pad A	E--173	Reverb Kick1
C5 72	IA-220	Soft Pad B	IA-220	Soft Pad B	IA-220	Soft Pad B	IA-220	Soft Pad B	IA-220	Soft Pad B	IA-220	Soft Pad B	IA-220	Soft Pad B	IA-058	Gtr Harm A
73	IB-118	Long Guiro	IB-118	Long Guiro	IB-118	Long Guiro	IB-118	Long Guiro	IB-118	Long Guiro	IB-118	Long Guiro	IB-118	Long Guiro	IA-010	Piano Thump
74	IB-118	Long Guiro	IB-118	Long Guiro	IB-118	Long Guiro	IB-118	Long Guiro	IB-118	Long Guiro	IB-118	Long Guiro	IB-118	Long Guiro	E--182	Crack Snare
75	IB-105	Claves	IB-105	Claves	IB-105	Claves	IB-105	Claves	IB-105	Claves	IB-105	Claves	IB-105	Claves	IB-096	Hand Claps
76	IB-104	Wood Block	IB-104	Wood Block	IB-104	Wood Block	IB-104	Wood Block	IB-104	Wood Block	IB-104	Wood Block	IB-104	Wood Block	E--178	Cross SN
77	IB-104	Wood Block	IB-104	Wood Block	IB-104	Wood Block	IB-104	Wood Block	IB-104	Wood Block	IB-104	Wood Block	IB-104	Wood Block	IB-072	808 SN
78	IB-121	Cuica	IB-121	Cuica	IB-121	Cuica	IB-121	Cuica	IB-121	Cuica	IB-121	Cuica	IB-121	Cuica	IA-098	PowerChord B
79	IB-121	Cuica	IB-121	Cuica	IB-121	Cuica	IB-121	Cuica	IB-121	Cuica	IB-121	Cuica	IB-121	Cuica	IB-080	Hybrid Kick2
80	IB-120	Open Triangl	IB-120	Open Triangl	IB-120	Open Triangl	IB-120	Open Triangl	IB-120	Open Triangl	IB-120	Open Triangl	IB-120	Open Triangl	E--240	REV Stacc f
81	IB-120	Open Triangl	IB-120	Open Triangl	IB-120	Open Triangl	IB-120	Open Triangl	IB-120	Open Triangl	IB-120	Open Triangl	IB-120	Open Triangl	E--212	Claps Real
82	IB-116	Cabasa Cut	IB-116	Cabasa Cut	IB-116	Cabasa Cut	IB-116	Cabasa Cut	IB-116	Cabasa Cut	IB-116	Cabasa Cut	IB-116	Cabasa Cut	IA-109	Banjo B
83	IB-053	Spectrum	IB-053	Spectrum	IB-053	Spectrum	IB-053	Spectrum	IB-053	Spectrum	IB-053	Spectrum	IB-053	Spectrum	IA-137	Slap Bass 1
C6 84	E--141	Orch Hit Maj	E--141	Orch Hit Maj	E--141	Orch Hit Maj	E--141	Orch Hit Maj	E--141	Orch Hit Maj	E--141	Orch Hit Maj	E--141	Orch Hit Maj	IA-165	Oboe mf A
85	E--142	Orch Hit Min	E--142	Orch Hit Min	E--142	Orch Hit Min	E--142	Orch Hit Min	E--142	Orch Hit Min	E--142	Orch Hit Min	E--142	Orch Hit Min	IA-161	Shakuhachi
86	E--143	Orch hit Dim	E--143	Orch hit Dim	E--143	Orch hit Dim	E--143	Orch hit Dim	E--143	Orch hit Dim	E--143	Orch hit Dim	E--143	Orch hit Dim	IA-212	Pizz
87	E--144	Orch Hit f	E--144	Orch Hit f	E--144	Orch Hit f	E--144	Orch Hit f	E--144	Orch Hit f	E--144	Orch Hit f	E--144	Orch Hit f	IA-237	Syn Vox 1
88	E--145	Staccato p	E--145	Staccato p	E--145	Staccato p	E--145	Staccato p	E--145	Staccato p	E--145	Staccato p	E--145	Staccato p	IA-239	Voice Aahs A
89	E--146	Staccato f	E--146	Staccato f	E--146	Staccato f	E--146	Staccato f	E--146	Staccato f	E--146	Staccato f	E--146	Staccato f	IA-245	Voice Oohs2A
90	IB-060	Orch. Hit	IB-060	Orch. Hit	IB-060	Orch. Hit	IB-060	Orch. Hit	IB-060	Orch. Hit	IB-060	Orch. Hit	IB-060	Orch. Hit	IA-236	Pop Voice
91	IB-061	Tekno Hit	IB-061	Tekno Hit	IB-061	Tekno Hit	IB-061	Tekno Hit	IB-061	Tekno Hit	IB-061	Tekno Hit	IB-061	Tekno Hit	IA-249	Male Ooh A
92	IB-062	Back Hit	IB-062	Back Hit	IB-062	Back Hit	IB-062	Back Hit	IB-062	Back Hit	IB-062	Back Hit	IB-062	Back Hit	IA-248	Voice Breath
93	IB-063	Philly Hit	IB-063	Philly Hit	IB-063	Philly Hit	IB-063	Philly Hit	IB-063	Philly Hit	IB-063	Philly Hit	IB-063	Philly Hit	IA-254	Org Vox C
94	IB-064	Scratch 1	IB-064	Scratch 1	IB-064	Scratch 1	IB-064	Scratch 1	IB-064	Scratch 1	IB-064	Scratch 1	IB-064	Scratch 1	IA-255	Vox Noise
95	E--166	Scratch 3	E--166	Scratch 3	E--166	Scratch 3	E--166	Scratch 3	E--166	Scratch 3	E--166	Scratch 3	E--166	Scratch 3	IA-255	Vox Noise
C7 96	IB-180	Metronome 2	IB-180	Metronome 2	IB-180	Metronome 2	IB-180	Metronome 2	IB-180	Metronome 2	IB-180	Metronome 2	IB-180	Metronome 2	E--160	Harp m7 DnLp
97	IB-178	R8 Click	IB-178	R8 Click	IB-178	R8 Click	IB-178	R8 Click	IB-178	R8 Click	IB-178	R8 Click	IB-178	R8 Click	IB-178	R8 Click
98	IB-179	Metronome 1	IB-179	Metronome 1	IB-179	Metronome 1	IB-179	Metronome 1	IB-179	Metronome 1	IB-179	Metronome 1	IB-179	Metronome 1	IB-180	Metronome 2

- In order to play Rhythm Sets on the JV-90/1000, you need to select the Rhythm Set for the Rhythm Part in the Performance mode, then use the buttons for the Rhythm mode to play the sounds.
- On the JV-90, you will also find the W-EXP A and W-EXP B Rhythm Sets at W-EXP C and W-EXP D (" E- " and " E. ," respectively, in the display).

- JV-90/1000でリズム・セットを演奏するときは、パフォーマンス・モードのリズム・パートでリズム・セットを選択した後、リズム・モードのボタンを押して演奏してください。
- JV-90では、W-EXP C (表示 E-), W-EXP D (表示 E.)にもW-EXP AとW-EXP Bのリズム・セットが搭載されています。

PATCH LIST for JV-80 / 880 / 90 / 1000

No.	Name
1	Ac.Piano 1
2	Ac.Piano 2
3	Soft Piano
4	U-220 APiano
5	FortePiano
6	Honky Tonk
7	Pop Piano
8	NewAge Piano
9	E.Grand 1
10	E.Grand 2
11	E.Grand mod
12	U-220 EGrand
13	Stage EGrand
14	E.Grand ff
15	E.Piano mod
16	Soft Rhodes
17	St.Rhodes
18	Tremolo EP
19	Bright EP 1
20	Bright EP 2
21	Bright EP 3
22	Bright EP 4
23	Syn.E.Piano
24	Hps Front 1
25	Hps Front 2
26	Hps Front 3
27	Hps Back 1
28	Hps Back 2
29	Hps Back 3
30	Hps Back 1T
31	Hps F/B
32	Hps F4/B
33	Hps F/B/B4
34	Hps Lute 1
35	Hps Lute 2
36	Hps Lute 3
37	Hps Lute 1T
38	Medieval Ens
39	Baroque Ens.
40	House Clav.
41	Org Flutes 1
42	Org Flutes 2
43	Org Flutes 3
44	Org Flute 8'
45	Church Organ
46	English Org
47	Organ Chord
48	Happy Xmas !
49	1001 Nights
50	Clavi Pad

No.	Name
51	into Dream
52	Box Guitar 1
53	Box Guitar 2
54	V-MX Guitar
55	Flat Picker
56	Steel Guitar
57	BriteJGuitar
58	Tympanon
59	Arabic Scale
60	Big Twelve
61	Jazz Guitar
62	St.Jazz Gtr
63	Pedal Steel1
64	Pedal Steel2
65	Stereo Pedal
66	Pedal Steel3
67	Dyno Steel
68	Super Pedal
69	Pedal Steel4
70	PedalSteelSw
71	Steel Fours
72	335 Guitar
73	St.335 Pick
74	335 VSW Pick
75	335 Mute
76	335 St. Mute
77	Echo Mute
78	VeloMute+Pik
79	All Mutes
80	Mute Guitar
81	BriteChorus
82	Clean Pick 1
83	Clean Pick 2
84	Clean E.Gtr
85	Super Picker
86	St. Pick
87	Dist Guitar
88	St.Dist Gtr
89	Super Heavy
90	Mandolin 1
91	Mandolin 2
92	Mandolin 3
93	Mandolin 4
94	Mandolins
95	SuperMando
96	ResonatorGt1
97	ResonatorGt2
98	ResonatorGt3
99	Dobraccent
100	Dulcimer 1

No.	Name
101	Dulcimer 2
102	Dulcimer 3
103	Guitar Pad
104	Bass mix
105	Musette tun
106	Musette det1
107	Musette det2
108	Master1
109	Master2
110	Jazz
111	Bandoneon1
112	Bandoneon2
113	Bs/Musettun
114	Bs/Musetdet1
115	Bs/Musetdet2
116	Bs/Master1
117	Bs/Master2
118	Bs/Jazz
119	Bs/Bandneon1
120	Bs/Bandneon2
121	Reed Organ1
122	Reed Organ2
123	Rive Gauche
124	Iturbynth
125	Amsterdam
126	Sad Musette
127	Fiddle 1
128	Fiddle 2
129	Super Fiddle
130	Fiddle About
131	DigitalCello
132	Four Seasons
133	Staccato
134	Tremolo 1 /
135	Tremolo 2
136	Tremolo 3 /
137	Sop Rec 1T
138	Tenor Rec 1T
139	Rec Twin
140	Rec Sect
141	Living Pipe
142	Pipe Lead
143	Whistle
144	Fr'm ScotInd
145	Soft Sax
146	Bright Sax
147	St.Sax
148	Bright TP
149	Trombone
150	Trombone SW

No.	Name
151	Twinbone
152	Super TB
153	St.Trombone
154	St.Soft TB
155	St.Bright TB
156	Brass Sect 1
157	Brass Sect 2
158	Brass Sect 3
159	Sax Sect 1
160	Sax Sect 2
161	In the Mood
162	Orchestra
163	BrassOrchest
164	Jazz Quartet
165	B!G Stab
166	Brass Fall 1
167	Brass Fall 2
168	Brass Fall 3
169	Tp Fall 1
170	Tp Fall 2
171	Brass Stacc
172	F.Horn Rip 1
173	F.Horn Rip 2
174	Mild ANALOG
175	Black Ring
176	Steel Brass
177	S.JV Marine
178	CarminaB/Aft
179	Cosmic Vox
180	Digital Vox
181	¥ Empire
182	Cosmic Echo
183	Sine Strings
184	Chineez Wave
185	Metalattack
186	EG Vox
187	Metal Sweep
188	Digi Sweep
189	Deep Space
190	Blue Mist
191	Trailer Pipe
192	Cluster
193	Pentatonic
194	Nothing Air
195	Mello Orch.
196	Orch Hit Maj
197	Orch Hit Min
198	Orch Hit Dim
199	Big Hits Maj
200	Finare /

No.	Name
201	Owz it !
202	Rave OrcHit
203	OrchGlissMaj
204	OrchGlissMin
205	Harp m7
206	Harp 9th
207	Harp +7
208	Harp b9
209	Harp m7 Scrl
210	Harp 9thScrl
211	Harp +7 Scrl
212	Harp b9 Scrl
213	Drum Set 1
214	Drum Set 2
215	Drum Set 3
216	Drum Set 4
217	Drum Set 5
218	Drum Set 6
219	Drum Set 7
220	CountryDrums

- Refer to the owner's manual for your instrument for specific instructions on how to play Patches on the expansion board.
  On the JV-80/880 and JD-990, a "Load" of the Patches needs to performed.
- On the JV-80/880/90/1000, you can not select the Patches which are designed to be used with JV-1010/1080/2080 and XP series.
- On the JD-990, you can use Patches designed to be used with the JV-80/880/90/1000 if you "Convert Load" them first. However, such Patches will sound slightly different than they would if played on the JV-80/880/90/1000.

- **エクスパンション・ボードのパッチを発音させるときは、使用機器の取扱説明書にしたがって、実行してください。**
  JV-80/880, JD-990では、パッチのロードを実行する必要があります。
- **JV-80/880/90/1000では、JV-1010/1080/2080, XPシリーズ専用のパッチを選ぶことはできません。**
- **JD-990で、JV-80/880/90/1000専用のパッチをコンバート・ロードして使用することができます。その場合、JV-80/880/90/1000で使用したときの音色とは多少異なります。**

PATCH LIST for JV-1010/1080/2080, XP series

No.	Name
1	Ac.Piano 1
2	Ac.Piano 2
3	Soft Piano
4	U-220 APiano
5	FortePiano
6	Honky Tonk
7	Pop Piano
8	Dusty Piano
9	NewAge Piano
10	E.Grand 1
11	E.Grand 2
12	E.Grand mod
13	U-220 EGrand
14	Stage EGrand
15	E.Grand ff
16	E.Piano mod
17	Soft Rhodes
18	St.Rhodes
19	Tremolo EP
20	Long is...
21	...the Road
22	High Rhodes
23	Bright EP 1
24	Bright EP 2
25	Bright EP 3
26	Bright EP 4
27	Syn.E.Piano
28	Xmod E.Piano
29	<D>gtalPiano
30	Hps Front 1
31	Hps Front 2
32	Hps Front 3
33	Hps Back 1
34	Hps Back 2
35	Hps Back 3
36	Hps Back 1T
37	Hps F/B
38	Hps F4/B
39	Hps F/B/B4
40	Hps Lute 1
41	Hps Lute 2
42	Hps Lute 3
43	Hps Lute 1T
44	Medieval Ens
45	Baroque Ens.
46	'60 CompKlav
47	House Clav.
48	Phase Clav.
49	Org Flutes 1
50	Org Flutes 2
51	Org Flutes 3
52	Org Flute 8'
53	Church Organ
54	English Org
55	Organ Chord
56	Happy Xmas !
57	1001 Nights
58	G.Star 1
59	G.Star 2
60	Dream Time

No.	Name
61	Clavi Pad
62	into Dream
63	Not Old
64	Box Guitar 1
65	Box Guitar 2
66	Reso Guitar
67	V-MX Guitar
68	Flat Picker
69	Steel Guitar
70	Steel there!
71	BriteJGuitar
72	Tympanon
73	Live Guitar
74	Arabic Scale
75	Big Twelve
76	Jazz Guitar
77	St.Jazz Gtr
78	Pedal Steel1
79	Pedal Steel2
80	Stereo Pedal
81	Pedal Steel3
82	Dyno Steel
83	Super Pedal
84	Pedal Steel4
85	PedalSteelSw
86	Steel Fours
87	Pedal Steel5
88	Clean'd Comp
89	Blues Guitar
90	335 Guitar
91	St.335 Pick
92	335 VSW Pick
93	335 Mute
94	335 St. Mute
95	Echo Mute
96	VeloMute+Pik
97	All Mutes
98	Mute Guitar
99	BriteChorus
100	Clean Pick 1
101	Clean Pick 2
102	Clean E.Gtr
103	Phase Guitar
104	PickChordsX4
105	Super Picker
106	St. Pick
107	Dist Guitar
108	HEAVY !
109	St.Dist Gtr
110	Super Heavy
111	Mandolin 1
112	Mandolin 2
113	Mandolin 3
114	Mandolin 4
115	Mandolins
116	SuperMando
117	ResonatorGt1
118	ResonatorGt2
119	ResonatorGt3
120	Dobraccent

No.	Name
121	Dulcimer 1
122	Dulcimer 2
123	Dulcimer 3
124	Gamelan Ens.
125	Guitar Pad
126	Bass mix
127	Musette tun
128	Musette det1
129	Musette det2
130	Master1
131	Master2
132	Jazz
133	Bandoneon1
134	Bandoneon2
135	Bs/Musettun
136	Bs/Musetdet1
137	Bs/Musetdet2
138	Bs/Master1
139	Bs/Master2
140	Bs/Jazz
141	Bs/Bandneon1
142	Bs/Bandneon2
143	Reed Organ1
144	Reed Organ2
145	Rive Gauche
146	Iturbynth
147	Bandneon Duo
148	Amsterdam
149	Sad Musette
150	Fiddle 1
151	Fiddle 2
152	Super Fiddle
153	Fiddle About
154	DigitalCello
155	Four Seasons
156	Staccato
157	Tremolo 1 /
158	Tremolo 2
159	Tremolo 3 /
160	Sop Rec 1T
161	Tenor Rec 1T
162	Rec Twin
163	Rec Sect
164	Recorder 1T
165	Living Pipe
166	Pipe Lead
167	Whistle
168	Fr'm ScotInd
169	Soft Sax
170	Bright Sax
171	St.Sax
172	Bright TP
173	Trombone
174	Trombone SW
175	Twinbone
176	Super TB
177	St.Trombone
178	St.Soft TB
179	St.Bright TB
180	Fat Trombone

No.	Name
181	Brass Sect 1
182	Brass Sect 2
183	Brass Sect 3
184	Pizz Brass
185	Sax Sect 1
186	Sax Sect 2
187	In the Mood
188	Orchestra
189	BrassOrchest
190	Jazz Quartet
191	B!G Stab
192	Brass Fall 1
193	Brass Fall 2
194	Brass Fall 3
195	Tp Fall 1
196	Tp Fall 2
197	Brass Stacc
198	F.Horn Rip 1
199	F.Horn Rip 2
200	Mild ANALOG
201	Black Ring
202	Steel Brass
203	S.JV Marine
204	CarminaB/Aft
205	Cosmic Vox
206	Digital Vox
207	¥ Empire
208	Cosmic Echo
209	She does ...
210	Sine Strings
211	Chineez Wave
212	Metalattack
213	EG Vox
214	Metal Sweep
215	Digi Sweep
216	Deep Space
217	Blue Mist
218	Trailer Pipe
219	Cluster
220	Pentatonic
221	RoaringSpace
222	Deep Cave
223	Kokoro
224	Nothing Air
225	Mick'm House
226	Mello Orch.
227	Saturn
228	Orch Hit Maj
229	Orch Hit Min
230	Orch Hit Dim
231	Big Hits Maj
232	Finare /
233	Owz it !
234	Rave OrcHit
235	OrchHit X
236	OrchGlissMaj
237	OrchGlissMin
238	Orch End FX
239	Harp m7
240	Harp 9th

No.	Name
241	Harp +7
242	Harp b9
243	Harp m7 Scrl
244:	Harp 9thScrl
245	Harp +7 Scrl
246	Harp b9 Scrl
247	Grove 1
248	Drum Set 1
249	Drum Set 2
250	Drum Set 3
251	Drum Set 4
252	Drum Set 5
253	Drum Set 6
254	Drum Set 7
255	CountryDrums

- Refer to the owner's manual for your instrument for specific instructions on how to play Patches on the expansion board.
- On the JV-1010/1080/2080 and XP series, you can not select only the Patches which are designed to be used with the JV-80/880/90/1000.

- **エクスパンション・ボードのパッチを発音させるときは、使用機器の取扱説明書にしたがって、実行してください。**
- **JV-1010/1080/2080, XPシリーズでは、JV-80/880/90/1000専用のパッチを選ぶことはできません。**

00786812 '99-5-C3-21K